


Q U I C K
S T A R T
G U I D E



W A G O N E E R



HomeLink® Buttons

Driver Seat
Controls


Cruise Control
Buttons

ON/OFF &
Volume

Light Controls

Instrument Cluster
Display Control Buttons

Drive Mode
Selector



Overhead Console

Tune/Browse

Passenger Screen
Display


Passenger Seat
Controls

Climate Controls

Front Comfort &
Convenience Display

Air Suspension Control

GARAGE DOOR OPENER



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:

Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.



ROLLING OR NON-ROLLING?

Check your garage door opener motor in your garage for a “LEARN” or “TRAIN” button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3

For **Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For **Rolling Code** garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4

For **Rolling Code** garage door openers only, firmly push and release the “LEARN” or “TRAIN” button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle for two long presses.

5

If the programming was successful, your garage door should open and close with your chosen HomeLink® button.



NEED ASSISTANCE?

1-800-355-3515



Scan me

CONNECTED SERVICES

WITH CONNECTED SERVICES YOU CAN...



Lock Your Vehicle



Unlock Your Vehicle



Remote Start Your Vehicle



Cancel Remote Start



Activate Your Horn

HOW TO ACTIVATE YOUR REMOTE SERVICES

- 1 Press "Apps" on the touchscreen
- 2 Press "Activate Services"
- 3 Press "Activate Now"
- 4 There are two ways to activate: via email or via an agent. On the next page, you can either enter your name and email, or press "Call Care" to directly speak with an agent.

NOTE:

If you previously were registered at the dealership, enter your email and PIN to activate services.

MOPAR® YOUR WAY

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need



Custom vehicle dashboard



Access to your vehicle's Owner's Information



Schedule dealership service with ease



Obtain special offers on Mopar® services



View maintenance records**



Mobile vehicle commands**



Registration is simple. Scan the QR code below and provide your email address to get started.



** Requires an active Uconnect Connected Services subscription

*Canadian residents are not required to create a profile, as one is created when a Uconnect Connected Services account is activated.

GET PERSONALIZED BY REGISTERING

HEAD UP DISPLAY (HUD)

HOW TO CUSTOMIZE HUD:

1

Select "Settings" in the Instrument Cluster with the Up or Down Arrow button on the steering wheel.

2

Select "HUD" with the Right or Left Arrow button on the steering wheel. Press "OK".

3

Adjust available Settings like Content & Layout, Display Height, and Brightness. Press "OK" to change the setting.



Instrument Cluster Display
Control Buttons

NOTE:

HUD will appear in your windshield

TIP:

Select from four available options:
Standard, Simple, Advanced, and Custom.



Scan me

CRUISE CONTROL SYSTEMS

ACC Distance
Increase

Set Speed or
Increase Speed

ACC
On/Off

Cruise Control
On/Off

Cancel

Resume

ACC Distance
Decrease

Set Speed or
Decrease Speed



The Cruise Control system will hold your vehicle's speed when you take your foot off of the accelerator.



The Adaptive Cruise Control (ACC) system will adjust the set speed in order to maintain a set distance from the vehicle in front of yours.

TIP:

The ACC distance setting appears in the instrument cluster display



Scan me

PAIR A PHONE



1

Make sure Bluetooth® is enabled on your mobile device.

2

With the vehicle in the ACC or ON/RUN position, press the Phone button in the vehicle's touchscreen menu bar.

3

Press "Device Manager" and then "Add Device".
Follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port or pair your smartphone within Device Manager. The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.



If the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.



Apple CarPlay® is only compatible with iPhone5® or later and requires Siri being enabled in Settings.

MULTICOLOR AMBIENT LIGHTS

YOU CAN CHANGE THE COLOR OF YOUR AMBIENT LIGHTS!

- 1 Navigate to the Ambient Color Personalization setting within the Uconnect system.
- 2 This setting redirects to a new menu. Select one of five colors for the ambient lighting in the cabin.




Select a color for **Zone 1** by choosing one of the rectangles on the top row of the screen. The second set of rectangles adjust the color for **Zone 2**.



TIP:

The selected rectangles will be filled with color, while the others have outlines only.

KEY FOB



Your key fob supports Passive Entry, Keyless Enter 'n Go™, and more!



Scan me

Uconnect 5/5 NAV



Home

Customize your Home page by adding shortcut widgets



Media

Listen to radio stations or play music from your USB or Bluetooth® device



Comfort

Utilize your manual or automatic climate controls through your comfort settings



NW
Nav

Enter an address or search from multiple points of interest to navigate



Phone

Pair your Bluetooth®-enabled phone and make hands-free calls



Vehicle

Access radio and vehicle settings



Apps

Access the available apps installed on your Uconnect system

Swipe down to customize Profile options



Press and drag an icon to rearrange



FRONT PASSENGER SCREEN


This screen provides the passenger access to Radio, Rear Seat Entertainment, HDMI, and Navigation functions. It is located on the passenger side of the vehicle, above the glove compartment.

Push the Power button under the Front Passenger Screen or under the Controls tab within the Uconnect system.

The Passenger Screen Permissions menu within "Settings" will activate/deactivate features within the Passenger Screen.

FRONT PASSENGER SCREEN HEADPHONE PAIRING

- 1 In Device Manager, press "Add Device" or "Pair Bluetooth® Headphones"
- 2 Press "Search For Headphones"
- 3 Select the Headphones you wish to pair and follow the on-screen instructions



SEAT CONTROLS

20-WAY POWER FRONT SEATS



- 1 FRONT HEAD RESTRAINT ADJUST**
Adjust the head restraint up, down, forward or rearward
- 2 POWER LUMBAR**
Press the + or — switch to bring up the Seat menu. Adjust the lumbar support in/out or up/down
- BACK/THIGH BOLSTER**
Press the + or — switch to bring up the Seat menu. Extend or retract the seatback and seat cushion bolsters
- 3 MEMORY SETTINGS PROFILE**
Save your seat preferences and more to Memory Profile 1 or 2
- 4 SEAT CUSHION**
Adjust the seat cushion up, down, forward, or rearward, or tilt the angle of the cushion up or down
- 5 CUSHION EXTENDER**
Extend or retract the seat cushion
- 6 POWER MESSAGE**
Turn on and adjust the power massage settings to high, medium, and low, and choose from five massage types
- 7 UPPER AND LOWER SEATBACK**
Adjust the angle of the upper or lower seatback

SECOND & THIRD ROW SEATS

ADJUST, FOLD, AND UNFOLD YOUR REAR SEATS

Rear Seat Power Folding Switch

A one-touch power folding seat switch is located in the right rear trim panel inside the cargo area.



Second Row
Left Side Fold



Second Row
Right Side Fold



Third Row
Left Side
Fold/Unfold



Third Row
Right Side
Fold/Unfold



Third Row Power Recline Switch

Adjust the third row seatback angle forward/rearward for occupant comfort. This switch is located on the trim panel next to the seat.



Scan me

HANDS-FREE LIFTGATE

OPEN YOUR LIFTGATE WITHOUT
PRESSING A BUTTON

TO SET AN OPENING HEIGHT:

1

Open the liftgate fully, then manually pull down or push up to the desired height.

2

Push and hold the liftgate close button, located on the left side trim panel inside the cargo area, for three seconds. An audible chime will sound.



↔
Activation Zone



LIFTGATE NOT OPENING?

Use a straight in and out kicking motion within the activation zone.

A sweeping motion under the activation zone can also be used for hands-free activation.

NOTE:

The Hands-Free Liftgate feature can be turned on and off within the Uconnect system.



Scan me

REAR SEAT ENTERTAINMENT

GET STARTED:

You will be prompted to pair the remote, connect to a network, and sign into an Amazon account. You can also enable parental controls.

With Uconnect Rear Seat Entertainment, you can stream movies and music and much more!

- 1 Push the Power button on the remote or swipe on either of the Rear Touchscreens to turn on the screen
- 2 Select from one of the available apps or source inputs, like HDMI or USB, through the Amazon Fire TV interface



Scan me
(U.S. Residents Only)*

KNOW & GO

Download the Know & Go* app to your smartphone to discover more about the exciting features on your new Wagoneer/Grand Wagoneer using augmented reality, a features library, and push notifications.




AUX Port

HDMI Port

USB C Charging Port

GET TO KNOW YOUR REMOTE



REAR SEAT ENTERTAINMENT HEADPHONE PAIRING


































































- 1 Select "Settings" from the top menu on the Home screen
- 2 Select "Controllers & Bluetooth® Devices"
- 3 Select "Other Bluetooth® Devices"
- 4 Follow the on-screen prompts to pair your headphones

DID YOU KNOW?

You can download games from the Apps menu to play on your rear touchscreens.



WARNING & INDICATOR LIGHTS

	Air Bag		Battery Charge		Brake		Door Open		Electric Power Steering (EPS) Fault
	Electronic Throttle Control (ETC)		Engine Temperature		Hood Open		Liftgate Open		Night Vision Animal Detect
	Night Vision Pedestrian Detect		Oil Pressure		Oil Temperature		Rear Seat Belt Reminder		Seat Belt Reminder
	Transmission Temperature		Vehicle Security		4WD Low		Active Lane Management		Air Suspension Active
	Air Suspension Aerodynamic Height		Air Suspension Entry/Exit Indicator		Air Suspension Off-Road 1		Air Suspension Off-Road 2		Anti-Lock Brake System
	Auto HOLD! Fault		Electronic Park Brake		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Engine Check/Malfunction Indicator
	Forward Collision Warning (FCW) Off		Low Fuel		Low Washer Fluid		NEUTRAL		Night Vision Animal Detect
	Night Vision Pedestrian Detect		Oil Level Sensor Fault		Service 4WD		Service Active Lane Management		Service Adaptive Cruise Control (ACC)
	Service Forward Collision Warning (FCW)		Service Stop/Start System		Tire Pressure Monitoring System		TOW/HAUL		Towing Hook Breakdown
	Active Lane Management		Adaptive Cruise Control (ACC) Set With Target		Adaptive Cruise Control (ACC) Set Without Target		Auto HOLD!		Cruise Control SET
	Front Fog		Night Vision Active		Parking /Headlights On		Rear Seat Belt Fastened		Sport Mode
	Stop/Start Active		Turn Signal		Active Lane Management		Adaptive Cruise Control (ACC) Ready		Cruise Control Ready
	Hill Descent Control (HDC)		Rear Seat Unoccupied		Selec-Speed Control		High Beam		Night Vision Suppressed

Your vehicle may be equipped with different features than shown in this guide.

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2021 FCA US LLC. All Rights Reserved. Tous droits réservés. Wagoner is a registered trademark of FCA US LLC.

Wagoner est une marque déposée de FCA US LLC. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

WS_QSG_EN_USC_BA

First Edition