

2018 CHALLENGER QUICK REFERENCE GUIDE

INCLUDES SRT 392/SRT HELLCAT

VEHICLE USER GUIDE — IF EQUIPPED

Vehicle User Guide

Access your Owner's Information – right through your Uconnect 4C or 4C NAV touchscreen radio — If Equipped.

To access the Vehicle User Guide on your Uconnect Touchscreen: Push the Uconnect **Apps** button, then push the **Vehicle User Guide** icon on your touchscreen. No Uconnect registration is required.



Vehicle User Guide Touchscreen Icon

NOTE:

Vehicle User Guide features are not available while the vehicle is moving. If you try to access while the vehicle is in motion, the system displays: Feature not available while the vehicle is in motion.

Pre-Installed Features

<ul style="list-style-type: none">Your User Guide — Updated in real-time	<ul style="list-style-type: none">Available when and where you need it
<ul style="list-style-type: none">Touchscreen convenience	<ul style="list-style-type: none">Customizable interface
<ul style="list-style-type: none">Maintenance schedules and information	<ul style="list-style-type: none">Multilingual
<ul style="list-style-type: none">Comprehensive icon & symbol glossary	

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

PASSIVE ENTRY

Keyless Enter-N-Go — Passive Entry

The Keyless Enter-N-Go system is an enhancement to the vehicle's key fob. This feature allows you to lock and unlock the vehicle's door(s) and trunk without having to press the key fob lock or unlock buttons.

To Unlock From The Driver Or Passenger Side



Grab The Door Handle To Unlock

- With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the driver or passenger side door handle, grab either front door handle to unlock the door automatically.

To Lock The Vehicle

- Both front door handles have buttons located on the outside of the handle. With one of the vehicle's Keyless Enter-N-Go key fobs located outside the vehicle and within 5 ft (1.5 m) of the driver's or passenger front door handle, push the door handle button to lock the two doors and trunk.
- Do NOT grab the door handle, when pushing the door handle button. This could unlock the door(s).



Push The Button To Lock



Do NOT Grab The Handle When Locking

NOTE:

- If “Unlock All Doors 1st Press” is programmed, all doors will unlock when you grab hold of the front driver’s door handle. Additionally, all doors and the trunk will unlock with this option programmed when you push the trunk button.

- If a key fob is detected in the vehicle when locking the vehicle using the power door lock switch, the doors and trunk will unlock, and the horn will chirp three times. On the third attempt, your key fob can be locked inside the vehicle.
- After pushing the Keyless Enter-N-Go lock button, you must wait two seconds before you can lock or unlock the vehicle using the door handle. This is done to allow you to check if the vehicle is locked by pulling the door handle without the vehicle reacting and unlocking.
- If a Keyless Enter-N-Go door handle has not been used for 72 hours, the Keyless Enter-N-Go feature for that handle may time out. Pulling the deactivated front door handle will reactivate the door handle’s Keyless Enter-N-Go feature.

To Enter The Trunk



Trunk Release Button

- With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the deck lid, push the button located on the center of the light bar which is located on the deck lid above the license plate.

INSTRUMENT CLUSTER DISPLAY

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

Instrument Cluster Display

The instrument cluster display features an interactive driver display that is located in the instrument cluster. Pushing the controls on the left side of the steering wheel allows the driver to select vehicle information and Personal Settings.



Instrument Cluster Display Controls

- Push the **up** button to scroll upward through the main menus (Speedometer, mph/km/h, Vehicle Info, Performance Pages – SRT only, Driver Assist, Fuel Economy, Trip A, Trip B, Audio, Stored Messages, Screen Set Up).
- Push the **down** button to scroll downward through the main menu and submenus (Speedometer, mph/km/h, Vehicle Info, Driver Assist, Fuel Economy, Trip A, Trip B, Audio, Stored Messages, Screen Set Up).
- Push the **right** button to access the information screens or submenu screens of a main menu item.
- Push the **left** button to access the information screens or submenu screens of a main menu item.

PHONE PAIRING

- Push the **OK** button to access/select the information screens or submenu screens of a main menu item. Push and hold the OK button for two seconds to reset displayed/selected features that can be reset. Pushing OK button will also toggle between mph and km/h on the digital speedometer.

Compass Calibration

This compass is self-calibrating, which eliminates the need to set the compass manually. When the vehicle is new, the compass may appear erratic, and the cluster will display dashes (- -) until the compass is calibrated.

You may also calibrate the compass by completing one or more 360 degree turns (in an area free from large metal or metallic objects) until the dashes (- -) displayed in the cluster turn off. The compass will now function normally.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at

www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

Pairing Procedure

Mobile phone pairing is the process of establishing a wireless connection between a cellular phone and the Uconnect system.

Start Pairing Procedure On The Radio

Uconnect 4 With 7-inch Display



Uconnect 4 With 7-Inch Display

1. Place the ignition in the ACC or ON position.
2. Press the “Phone” button.
3. Select “Settings.”

4. Select “Paired Phones.”
5. Select “Add device.”

- Uconnect Phone will display an “In progress” screen while the system is connecting.

Uconnect 4C & 4C NAV With 8.4-inch Display



Uconnect 4C & 4C NAV With 8.4-Inch Display

1. Place the ignition in the ACC or ON position.
2. Press the “Phone” button in the Menu Bar on the touchscreen.

3. Select "Pairing."
4. Select "Paired Phones And Audio Devices."
5. Select "Add Device."
 - Uconnect Phone will display an "In progress" screen while the system is connecting.

Pair Your iPhone:




Bluetooth On/Uconnect Device

To search for available devices on your Bluetooth enabled iPhone:

1. Press the Settings button.
2. Select Bluetooth.
 - Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.
3. When your mobile phone finds the Uconnect system, select "Uconnect".

Complete The iPhone Pairing Procedure:




Pairing Request

1. When prompted on the mobile phone, accept the connection request from Uconnect Phone.

NOTE:

Some mobile phones will require you to enter the PIN number.

Pair Your Android Device:




Uconnect Device

To search for available devices on your Bluetooth enabled Android Device:

1. Push the Menu button.

2. Select Settings.
3. Select Connections.
4. Turn Bluetooth setting to “On.”
 - Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.
5. Once your mobile phone finds the Uconnect system, select “Uconnect”.
 - You may be prompted by your mobile phone to download the phonebook, check “Do Not Ask Again” to automatically download the phonebook. This is so you can make calls by saying the name of your contact.

Complete The Android Pairing Procedure:



Pairing Request

1. Confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system then accept the Bluetooth pairing request.

NOTE:

Some mobile phones require the PIN to be entered manually, enter the PIN number shown on the Uconnect screen.

NOTE:

Software updates on your phone or the Uconnect system may interfere with the Bluetooth connection. If this happens, simply repeat the pairing process. However, first, make sure to delete the device from the list of phones on your Uconnect system. Next, be sure to remove Uconnect from the list of devices in your phone's Bluetooth settings.

For further information on Uconnect Phone, please refer to “Uconnect Phone” in the vehicle's User Guide.

LIGHTS

Automatic High Beam — If Equipped

This system automatically controls the operation of the headlamp high beams as oncoming vehicles approach.

- The Automatic High Beam Headlamp Control can be turned on or off using the Uconnect System.
- Push the turn signal lever away from you.
- With the headlight switch in the “AUTO” position, the high beams are controlled automatically.

- Pull the turn signal lever toward you to manually deactivate the system.
- To improve system recognition of crossing traffic, and to limit use in a residential area, the vehicle must be moving at a speed greater than 20 mph (32 km/h) before the Automatic High Beam Module (AHBM) begins requesting high beam activation.

NOTE:

If the windshield or Automatic High Beam Headlamp Control mirror is replaced, the mirror must be re-aimed to ensure proper performance. See a local authorized dealer.

SPEED CONTROL

Adaptive Cruise Control (ACC) — If Equipped

If your vehicle is equipped with Adaptive Cruise Control, the controls operate exactly the same as the standard cruise control, with one difference. You can set a specified distance you would like to maintain between you and the vehicle in front of you.

- If the ACC sensor detects a vehicle ahead, ACC will apply limited braking or acceleration automatically to maintain a preset following distance while matching the speed of the vehicle ahead.

NOTE:

Your vehicle will not exceed the cruise speed you have set.

SAFETY FEATURES

- If the sensor does not detect a vehicle directly ahead of you, it functions like a standard cruise control system, maintaining the speed you set.



Adaptive Cruise Switches

- 1 — Adaptive Cruise Control (ACC) On/Off
- 2 — Distance Setting – Decrease
- 3 — Distance Setting – Increase

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

Forward Collision Warning — If Equipped

The Forward Collision Warning (FCW) system provides the driver with audible warnings, as well as visual warnings within the instrument cluster display, to warn the driver when a potential frontal collision is detected. The warnings are intended to provide the driver with enough time to react, to avoid or mitigate the potential collision.

FCW monitors the information from the forward looking sensors, as well as the Electronic Stability Control (ESC) system, to calculate the probability of a forward collision. When the system determines that a forward collision is probable, the driver will be provided with the audible and visual warnings.

STARTING AND OPERATING

NOTE:

The FCW feature can be customized and turned off through the Uconnect System touchscreen.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at

www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

SRT Vehicles

Chassis

- Wheels - due to the high performance nature of the brake system, the wheels will get coated with brake dust. It is recommended that Mopar® Wheel Cleaner be used on your wheels to avoid any possible damage to the finish. However, do not use wheel cleaner if your vehicle is equipped with Dark Vapor or Black Satin Chrome wheels, which must only be cleaned with mild soap, water, and a soft cloth.

NOTE:

Due to the high performance nature of the brakes on your SRT, vehicle dust and some noise are expected and normal.

- Tire Service Kit - your vehicle comes with a tire inflator kit; there is no spare tire included in your vehicle.
- Trailer Tow - Trailer towing with your SRT vehicle is not recommended.

- ESC (Electronic Stability Control) - your vehicle is equipped with selectable ESC modes. The ESC mode selected will alter the handling characteristics of your vehicle.
- Adjustable Modes - your vehicle is equipped with selectable driving modes: Default (Street), Sport, Track, Custom, ECO, and Valet. Please refer to the Owner's Manual for further information.
- Three-Season Tires - This vehicle may be equipped with three-season tires to enhance performance. FCA US LLC does not recommend use of these tires when temperatures are below 40°F (4°C) or in snow/ice conditions.



Powertrain & Drivetrain

- Engine & Transmission (SRT Engine Break-In Recommendations) - The following tips will be helpful in obtaining optimum performance and maximum durability for your new SRT Vehicle. Despite modern technology and World Class manufacturing methods, the moving parts of the vehicle must still wear in with each other. This wearing in occurs mainly during the first 500 miles (805 km) and continues through the first oil change interval.

NOTE:

Check engine oil with every refueling and add if necessary. Oil and fuel consumption may be higher through the first oil change interval.

- Engine Oil - 0W-40 Full Synthetic Engine Oil recommended.
- Fuel - for optimum performance, Premium Fuel with a minimum octane rating of 91 Pump Octane Number (97 RON) is recommended.

Automatic Transmission:

- Applying the brake and throttle pedals at the same time [“brake torquing”] for an extended period of time will illuminate the ETC fault light requiring the dealership to clear.
- The vehicle may be equipped with steering wheel mounted “Paddle Shifters” and an M gate console shifter. When in the M gate, the vehicle will not shift at red line and must be manual shifted with either the paddle shifters or the console shifter. In the M gate, the shift light can be programed to assist the driver with optimal shift points.

Launch Control:

- Your car may be equipped with Launch Control to improve acceleration performance. It is activated by pressing the LAUNCH or Super Track Pack (if equipped) button, located in the instrument panel switch bank, as well as in the radio within “Race Options”, and will help control tire spin for maximum acceleration. The launch RPM is also selectable through the race options screens. Launch Control is not available for the first 500 miles of vehicle life.

Manual Transmission:

- Your vehicle is equipped with a 1-4 skip shift feature to maximize fuel economy. Under certain conditions, the vehicle will require you to shift the transmission from first to fourth gear, instead of from first gear to second gear. Skip Shift is only active while in normal or default driving mode. The detailed conditions of this feature are described in the Owner’s Manual.
- Do not attempt to shift the transmission if the rear wheels are spinning due to loss of traction. Damage to the transmission may occur.
- When shifting, fully depress the clutch pedal and lift off the accelerator pedal before shifting gears. Damage to the transmission or clutch may occur if you do not fully depress the clutch pedal and lift off the accelerator pedal when shifting.
- Do not rest your hand on the gear shift knob while driving. This may cause premature wear of the transmission synchronizers.
- Do not rest your foot on the clutch pedal while driving. This may cause premature wear of the clutch.

Body & Exterior

- Fascias and Ground Effects - This vehicle has a unique exterior appearance, which includes SRT unique fascias and ground effects. These exterior components define the style and appearance of your new vehicle. They also cause a lower approach angle in the front of the vehicle and reduced ground clearance. Due to lower ground clearance, driving your vehicle up steep driveways, approach ramps, or near parking blocks may cause damage to the front fascia and ground effects.
- If your vehicle is equipped with a SATIN FINISH Exterior Body Paint: Use products made specifically for satin paint, such as Swissvax Opaque Satin Paint Wax and Dr. Beasley's Satin Paint and Sealant. Reference Satin Finish Tips Card.
- Caution should be taken when driving through water or snow more than 4 inches (100 mm) deep to avoid any potential for damage to your vehicle.

Electrical

- Your vehicle may be equipped with a premium “harman/kardon” sound system. Your audio mode can be configured using the radio.
- Your vehicle is equipped with SRT performance pages, Drive Modes, Performance Shift Indication, Launch Control, and Valet Mode, which are displayed in the instrument cluster and the radio.
- Valet Mode is offered on all SRT vehicles. The driver can activate and deactivate Valet Mode with a four-digit PIN they create. Custom PIN's are created with each use. If you forget your PIN, disconnect the battery for five minutes to reset.
- Your vehicle may be equipped with a Red key fob, in addition to the Black key fob. The Red key is the only key that can unlock the full horsepower and torque potential of the SRT Hellcat engine, while the Black key fob limits the driver to reduced engine output and reduction of transmission shift schedules. In addition, the Red key fob will unlock all the options within Drive Modes. The Black key fob will limit your options within Drive Modes.

- If equipped with an Automatic Transmission, your vehicle offers an ECO mode. ECO mode will change the feel of the throttle response and shift patterns. Please see the Owner's Manual for further information on configuration that are automatically adjusted.

For additional information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents) for further information.

SIRIUSXM GUARDIAN — IF EQUIPPED

Activation

To use SiriusXM Guardian emergency, remote and security services, you must activate your SiriusXM Guardian account.

1. Press the Apps icon on the bottom of your in-vehicle touchscreen.
2. Select the “Activate Services” icon from your list of apps.
3. Select “Customer Care” to speak with a SiriusXM Guardian Customer Care agent who will activate services in your vehicle, or select “Enter Email” to activate on the web.

Once you have activated your services, you’re only a few steps away from using remote services.



Mobile App

To use SiriusXM Guardian remote services, download the Uconnect Mobile app:

- Once downloaded, use your Owner Account login and password to open the app.
- Include similar language: You will use your SiriusXM Guardian PIN to execute these remote services.

- Press the “Location” button on the bottom menu bar of the app to bring up a map to locate your vehicle or send a location to your Uconnect Navigation, if equipped.
- Press the “Settings” side menu in the upper left corner of the app to bring up app settings and access the Assist Call Centers.

For further information:

- U.S. residents visit: siriusxm.com/guardian
- Canadian residents visit: siriusxm.ca/guardian/

Features

SiriusXM Guardian keeps you connected to your vehicle. You have access to safety, remote and security services.



In-Vehicle Features

SiriusXM Guardian enhances your ownership and driving experience by connecting your vehicle to an operable network. When connected to an operable network, you have access to:

- **SOS Call:** Connect to a live agent who contact emergency services and stays on the line with you until help arrives.
- **Customer Care Assistance:** Speak with a live agent when you press the ASSIST button on your rearview mirror to get Roadside Assistance or support.

Remote Services

SiriusXM Guardian helps you activate features from a distance. The remote services are:

- **Vehicle Finder** helps you find where you parked your car.
- **Send & Go** allows you to send preset destinations to your navigation system for easy access on the go.
- **Remote Door Lock/Unlock** lets you unlock or lock your doors from any distance.
- **Remote Horn & Lights** allows you to sounds your horn and flash your lights to easily find your car.
- **Receive monthly Vehicle Health Reports, and Alerts** whenever a problem is detected under the hood.

Security Services

The Uconnect Mobile App helps you activate features from a distance. The remote services are:

- **Receive text or email notifications** if your vehicle's security alarm goes off.
- **Receive stolen vehicle assistance**, using GPS technology to help authorities locate your vehicle if it is stolen.

SiriusXM Guardian remote services can be used with the Uconnect app from virtually anywhere.

For further information on SiriusXM Guardian or the Uconnect Mobile App, refer to your Uconnect Owner's Manual Supplement.

Vehicle Finder And Send & Go

Two of the most convenient remote features of the Uconnect Mobile App are Vehicle Finder and Send & Go.

Vehicle Finder

Vehicle Finder allows you to find the location of your vehicle when you have lost it. You can also sound the alarm and flash the lights to make finding your vehicle even easier. To find your vehicle:

1. Press the “Location” tab on the Uconnect Mobile App bottom bar.
2. Select the “Vehicle” icon to determine the location of your vehicle.
3. Select the “Find Route” button that appears, once your vehicle is located.
4. Select your preferred Navigation App to route a path to your vehicle.

Send & Go

Send & Go allows you to search for a destination on your mobile device and then send the route to your vehicle’s built-in navigation system. To send a navigation route to your vehicle:

1. Press the “Location” tab on the Uconnect Mobile App bottom bar.
2. Either type in the destination you would like to navigate to, or search through one of the categories provided.
3. Select the destination you want to route to from the list that appears.
4. Press the “Send To Vehicle” button, and then confirm the destination by pressing “Yes,” to send the navigation route to the Uconnect Navigation in your vehicle.
5. Finally, confirm the route inside your vehicle by pressing the “Go Now” option on the pop-up that appears on the touchscreen, when the vehicle is started.


NOTE:

The Owner’s Mobile App content is applicable to vehicles sold in the U.S. market and are not available from the Canadian App Store or Google Play Store.

Key Features

- Owner Information For Your Vehicle
- Accident Assistant
- Online Service Scheduling
- Roadside Assistance
- Maintenance History
- And More

To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword “Dodge”.



The DRIVE DODGE Application is the essential app for owners of Dodge brand vehicles. The app puts driver and lifestyle information right in the palm of your hand, anywhere you go. Whether it's providing information about specific product features, taking a tour through your vehicle's equipment, staying up to date on your vehicle's health, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Dodge vehicle. Simply download the FREE app, select your make and model and enjoy the ride.

Features/Benefits

- Available for free on iOS and Android smartphones and tablets.
- Select Dodge brand vehicles from model year 2011 to current model year.
- You can also add other Chrysler, Jeep, Ram, FIAT or Alfa Romeo vehicles.*
- Easy access to vehicle information anywhere you go using categories, bookmarks, search and an A-Z index.
- Vehicle information such as operating instructions, maintenance, service history, vehicle controls and emergency procedures.
- Find a dealer or an FCA-certified repair facility.

- Easily document and email an accident report.
- A parking reminder that allows you to drop a pin on your location and navigate back to your vehicle.
- Contact customer care with one click.
- Access to vehicle heritage, parts, accessories, and social media networks.
- Schedule your next service appointment.
- Available in English and Spanish.

*App supports selected vehicles from model year 2011 to present.

To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword "Dodge".







Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident or scheduling your next appointment, we know you'll find the app an important extension of your Dodge brand vehicle. Simply download the app, select your make and model and enjoy the ride. To get this app, go directly to the App Store or Google Play and enter the search keyword "Dodge" (U.S. residents only).

www.dodge.com/en/owners (U.S.) provides special offers tailored to your needs, customized vehicle galleries, personalized service records and more. To get this information, just create an account and check back often.

Get warranty and other information online – you can review and print or download a copy of the Owner's Manual, Navigation/Uconnect manuals and the limited warranties provided by FCA US LLC for your vehicle by visiting www.mopar.com (U.S.) or www.owners.mopar.ca (Canada). Click on the applicable link in the "Popular Topics" area of the mopar.com (U.S.) or owners.mopar.ca (Canada) homepage and follow the instructions to select the applicable year, make and model of your vehicle.

DODGE

DOWNLOAD A FREE ELECTRONIC COPY
OF THE MOST UP-TO-DATE OWNER'S
MANUAL, MEDIA AND WARRANTY
BOOKLET BY VISITING:

WWW.MOPAR.COM/EN-US/CARE/OWNERS-MANUAL.HTML
(U.S. RESIDENTS);

WWW.OWNERS.MOPAR.CA
(CANADIAN RESIDENTS).

DODGE.COM (U.S.)

DODGE.CA (CANADA)

©2017 FCA US LLC. ALL RIGHTS RESERVED.
DODGE IS A REGISTERED TRADEMARK OF FCA US LLC.



18LA-QRG-AA
CHALLENGER
FOURTH EDITION
QUICK REFERENCE GUIDE