



2019 CHARGER QUICK REFERENCE GUIDE

VEHICLE USER GUIDE — IF EQUIPPED

Vehicle User Guide — If Equipped

To access the Vehicle User Guide on your Uconnect Touchscreen: Tap the Uconnect **Apps** button, then tap the **Vehicle User Guide** icon on your touchscreen. No Uconnect registration is required.



Uconnect 4C NAV With 8.4-inch Display
Vehicle User Guide Touchscreen Icon

NOTE:

Vehicle User Guide features are not available while the vehicle is moving.

Features

- Your User Guide — Updated in real-time
- Available when and where you need it
- Touchscreen convenience
- Customizable interface
- Maintenance schedules and information
- Multilingual
- Comprehensive icon & symbol glossary

PASSIVE ENTRY

Keyless Enter-N-Go — Passive Entry

The Keyless Enter-N-Go system is an enhancement to the vehicle's key fob. This feature allows you to lock and unlock the vehicle's door(s) and trunk without having to press the key fob lock or unlock buttons.

To Unlock From The Driver Or Passenger Side



Grab The Door Handle To Unlock

With a valid key fob located outside the vehicle and within 5 ft (1.5 m) of the driver or passenger side door handle, lift either front door handle to unlock the door automatically.

To Lock The Vehicle

Both front door handles have buttons located on the outside of the handle. With one of the vehicle's key fobs located outside the vehicle and within 5 ft (1.5 m) of the driver's or passenger front door handle, push the door handle button to lock all four doors and trunk.

Do NOT grab the door handle when pushing the lock button. This could unlock the door(s).



Push The Door Handle Passive Entry Button To Lock



Do NOT Grab The Handle When Locking

NOTE:

- If “Unlock All Doors 1st Press” is programmed, all doors will unlock when you grab hold of the front driver's door handle.
- If a key fob is detected in the vehicle when locking the vehicle using the power door lock switch, the doors will unlock and the horn will chirp three times. On the third attempt, your key fob can be locked inside the vehicle.
- After pushing the button, you must wait two seconds before you can lock or unlock the vehicle using the door handle. This is done to allow you to check if the vehicle is locked by pulling the door handle without the vehicle reacting and unlocking.
- If a Keyless Enter-N-Go — Passive Entry door handle has not been used for 72 hours, the Keyless Enter-N-Go — Passive Entry feature for that handle may time out. Pulling the deactivated front door handle will reactivate the door handle's Keyless Enter-N-Go — Passive Entry feature.

To Enter The Trunk



Trunk Passive Entry Button

With a valid key fob located outside the vehicle and within 5 ft (1.5 m) of the trunk, push the button on the right side of applique which is located on the trunk.

Whenever the vehicle is unlocked, you can enter the trunk by pushing the button on the right side of the applique.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

INSTRUMENT CLUSTER DISPLAY

Cluster Display

The instrument cluster display features a driver interactive display that is located in the instrument cluster. Pushing the controls on the left side of the steering wheel allows the driver to select Vehicle Information and Personal Settings.



Instrument Cluster Display Controls

- Push the **up** arrow button to scroll upward through the main menus (Speedometer, Vehicle Info, Performance Pages – SRT only, Driver Assist, Fuel Economy, Trip, Audio, Messages, Screen Setup) and sub menus.
- Push the **down** arrow button to scroll downward through the main menus and sub menu.
- Push the **right** arrow button to scroll forward to the next menu or sub menu.
- Push the **left** arrow button to scroll back to a previous menu or sub menu.
- Push the **OK** button to access/select the information screens, the submenu screens of a main menu item, or to select a personal setting in the setup menu. Push and hold the **OK** button for two seconds to reset displayed/selected features that can be reset.

Compass Calibration

This compass is self-calibrating, which eliminates the need to set the compass manually. When the vehicle is new, the compass may appear erratic, and the cluster will display dashes (- -) until the compass is calibrated.

You may also calibrate the compass by completing one or more 360 degree turns (in an area free from large metal or metallic objects) until the dashes (- -) displayed in the cluster turn off. The compass will now function normally.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

PHONE PAIRING

Pairing Procedure

Mobile phone pairing is the process of establishing a wireless connection between a cellular phone and the Uconnect system.

Start Pairing Procedure On The Radio

Uconnect 4 With 7-inch Display



Uconnect 4 With 7-Inch Display

1. Place the ignition in the ACC or ON position.
2. Press the “Phone” button.
3. Select “Settings.”

4. Select “Paired Phones.”
5. Select “Add device.”
 - Uconnect Phone will display an “In progress” screen while the system is connecting.

Uconnect 4C & 4C NAV With 8.4-inch Display



Uconnect 4C & 4C NAV With 8.4-Inch Display

1. Place the ignition in the ACC or ON position.
2. Press the “Phone” button in the Menu Bar on the touchscreen.
3. Select “Pairing.”
4. Select “Paired Phones And Audio Devices.”

5. Select “Add Device.”
 - Uconnect Phone will display an “In progress” screen while the system is connecting.

Pair Your iPhone:



Bluetooth On/Uconnect Device

To search for available devices on your Bluetooth enabled iPhone:

1. Press the Settings button.
2. Select Bluetooth.

- Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.

3. When your mobile phone finds the Uconnect system, select “Uconnect”.

Complete The iPhone Pairing Procedure:



Pairing Request

1. When prompted on the mobile phone, accept the connection request from Uconnect Phone.

NOTE:

Some mobile phones will require you to enter the PIN number.

Pair Your Android Device:




Uconnect Device

To search for available devices on your Bluetooth enabled Android Device:

1. Push the Menu button.
2. Select Settings.
3. Select Connections.
4. Turn Bluetooth setting to “On.”
 - Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.

5. Once your mobile phone finds the Uconnect system, select “Uconnect”.
 - You may be prompted by your mobile phone to download the phonebook, check “Do Not Ask Again” to automatically download the phonebook. This is so you can make calls by saying the name of your contact.

Complete The Android Pairing Procedure:



Pairing Request

1. Confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system then accept the Bluetooth pairing request.

NOTE:

Some mobile phones require the PIN to be entered manually, enter the PIN number shown on the Uconnect screen.

NOTE:

Software updates on your phone or the Uconnect system may interfere with the Bluetooth connection. If this happens, simply repeat the pairing process. However, first, make sure to delete the device from the list of phones on your Uconnect system. Next, be sure to remove Uconnect from the list of devices in your phone's Bluetooth settings.

For further information on Uconnect Phone, please refer to “Uconnect Phone” in the vehicle's User Guide.

LIGHTS

Automatic High Beam — If Equipped

This system automatically controls the operation of the headlamp high beams as oncoming vehicles approach.

- The Automatic High Beam Headlamp Control can be turned on or off using the Uconnect System.
- Push the turn signal lever away from you.
- With the headlight switch in the “AUTO” position, the high beams are controlled automatically.
- Pull the turn signal lever toward you to manually deactivate the system.
- To improve system recognition of crossing traffic, and to limit use in a residential area, the vehicle must be moving at a speed greater than 20 mph (32 km/h) before the Automatic High Beam Module (AHBM) begins requesting high beam activation.

NOTE:

If the windshield or Automatic High Beam Headlamp Control mirror is replaced, the mirror must be re-aimed to ensure proper performance. See an local authorized dealer.

For further information, and applicable warnings and cautions, please refer to the Owner’s Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

SPEED CONTROL

Adaptive Cruise Control (ACC) — If Equipped

If your vehicle is equipped with Adaptive Cruise Control, the controls operate exactly the same as the standard cruise control, with one difference. You can set a specified distance you would like to maintain between you and the vehicle in front of you.

- If the ACC sensor detects a vehicle ahead, ACC will apply limited braking or acceleration automatically to maintain a preset following distance while matching the speed of the vehicle ahead.

NOTE:

Your vehicle will not exceed the cruise speed you have set.

- If the sensor does not detect a vehicle directly ahead of you, it functions like a standard cruise control system, maintaining the speed you set.

SAFETY FEATURES



Adaptive Cruise Switches

- 1 — Adaptive Cruise Control (ACC) On/Off
- 2 — Distance Setting – Decrease
- 3 — Distance Setting – Increase

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

LaneSense — If Equipped

The LaneSense system is operational at speeds above 37 mph (60 km/h) and below 112 mph (180 km/h). The LaneSense system uses a forward looking camera to detect lane markings and measure vehicle position within the lane boundaries.

Turning LaneSense On Or Off

The default status of LaneSense is “off”. The LaneSense button is located on the center stack.

LaneSense Warning Message

The LaneSense system will indicate the current lane drift condition through the instrument cluster display. The instrument cluster display will provide a visual warning depicting the unintentional lane departure.

When both lane markings are detected and the driver unintentionally drifts out of the lane (no turn signal applied), the LaneSense system provides a haptic warning in the form of torque applied to the steering wheel to prompt the driver to remain within the lane boundaries. The driver may manu-

ally override the haptic warning by applying torque into the steering wheel at any time. When only a single lane marking is detected and the driver unintentionally drifts across the lane marking (no turn signal applied), the LaneSense system provides a visual warning through the instrument cluster display to prompt the driver to remain within the lane. When only a single lane marking is detected, a haptic (torque) warning will not be provided.

NOTE:

The LaneSense system can be customized and turned off through the Uconnect System touchscreen.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

Forward Collision Warning With Mitigation — If Equipped

The Forward Collision Warning (FCW) system provides the driver with active braking, audible and visual warnings [within the instrument cluster display] and may apply a brake jerk to warn the driver when it detects a potential frontal collision. The warnings and limited braking are intended to provide the driver with enough time to react and avoid or mitigate the potential collision.

FCW monitors the information from the forward-looking sensor, as well as the Electronic Brake Controller (EBC) to calculate a probable collision. When the system determines that a collision is probable, a warning message (both audible and visual) will be displayed within the cluster display along with a brake jerk warning (previously enabled in the Uconnect Settings). When the system senses the driver applying the brakes to avoid a probable collision, additional brake force will be provided to the vehicle. When the system determines a collision with the vehicle in front of you is no longer probable, the warning message will be deactivated.

NOTE:

The FCW feature can be customized and turned off through the Uconnect System touchscreen.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

STARTING AND OPERATING

SRT Vehicles

Chassis

- Wheels - due to the high performance nature of the brake system, the wheels will get coated with brake dust. It is recommended that Mopar® Wheel Cleaner be used on your wheels to avoid any possible damage to the finish. However, do not use wheel cleaner if your vehicle is equipped with Dark Vapor or Black Satin Chrome wheels, which must only be cleaned with mild soap, water, and a soft cloth.

NOTE:

Due to the high performance nature of the brakes on your SRT, vehicle dust and some noise are expected and normal.

- Tire Service Kit - your vehicle comes with a tire inflator kit; there is no spare tire included in your vehicle.
- Trailer Tow - Trailer towing with your SRT vehicle is not recommended.
- ESC (Electronic Stability Control) - your vehicle is equipped with selectable ESC modes. The ESC mode selected will alter the handling characteristics of your vehicle.

- Adjustable Modes - your vehicle is equipped with selectable driving modes: Default (Street), Sport, Track, Custom, ECO, and Valet.
- Three-Season Tires - This vehicle may be equipped with three-season tires to enhance performance. FCA US LLC does not recommend use of these tires when temperatures are below 40°F (4°C) or in snow/ice conditions.

Powertrain & Drivetrain

- Engine & Transmission (SRT Engine Break-In Recommendations) - The following tips will be helpful in obtaining optimum performance and maximum durability for your new SRT Vehicle. Despite modern technology and World Class manufacturing methods, the moving parts of the vehicle must still wear in with each other. This wearing in occurs mainly during the first 500 miles (805 km) and continues through the first oil change interval. For complete break-in driving procedure, refer to the Owner's Manual.

NOTE:

Check engine oil with every refueling and add if necessary. Oil and fuel consumption may be higher through the first oil change interval.

- Engine Oil - 0W-40 Full Synthetic Engine Oil recommended.
- Fuel - for optimum performance, Premium Fuel with a minimum octane rating of 91 Pump Octane Number is recommended.

Transmission:

- Applying the brake and throttle pedals at the same time, also known as “brake torquing”, for an extended period of time will illuminate the ETC fault light requiring the dealership to clear.
- The vehicle may be equipped with steering wheel mounted “Paddle Shifters” and an M gate console shifter. When in the M gate the vehicle will not shift at red line and must be manual shifted with either the paddle shifters or the console shifter. In the M gate, the shift light can be programed to assist the driver with optimal shift points.

Launch Control:

- Your car may be equipped with Launch Control to improve acceleration performance. It is activated by pressing the LAUNCH button, located in the instrument panel switch bank, as well as in the radio within “Race Options”, and will help

control tire spin for maximum acceleration. The launch RPM is also selectable through the race options screens. Launch Control is not available for the first 500 miles (805 km) of vehicle life.

Body & Exterior

- Fascias and Ground Effects - This vehicle has a unique exterior appearance, which includes SRT unique fascias and ground effects. These exterior components define the style and appearance of your new vehicle. They also cause a lower approach angle in the front of the vehicle and reduced ground clearance. Due to lower ground clearance, driving your vehicle up steep driveways, approach ramps, or near parking blocks may cause damage to the front fascia and ground effects.
- If your vehicle is equipped with a SATIN FINISH Exterior Body Paint: Use products made specifically for satin paint, such as Swissvax Opaque Satin Paint Wax and Dr. Beasley's Satin Paint and Sealant. Reference Satin Finish Tips Card.
- Caution should be taken when driving through water or snow more than 4 inches (100 mm) deep to avoid any potential for damage to your vehicle.

Electrical

- Your vehicle may be equipped with a premium “harman/kardon” sound system. Your audio mode can be configured using the radio.
- Your vehicle is equipped with SRT performance pages, Drive Modes, Performance Shift Indication, Launch Control, and Valet Mode, which are displayed in the instrument cluster and the radio.
- Valet Mode is offered on all SRT vehicles. The driver can activate and deactivate Valet Mode with a four-digit PIN they create. Custom PIN's are created with each use. If you forget your PIN, disconnect the battery for five minutes to reset.
- Your vehicle may be equipped with a Red key fob, in addition to the Black key fob. The Red key is the only key that can unlock the full horsepower and torque potential of the SRT Hellcat engine, while the Black key fob limits the driver to reduced engine output and reduction of transmission shift schedules. In addition, the Red key fob will unlock all the options within Drive Modes. The Black key fob will limit your options within Drive Modes.

- Your vehicle offers an ECO mode. ECO mode will change the feel of the throttle response and shift patterns. Please see the Owner's Manual for further information on configuration that are automatically adjusted.

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

SIRIUSXM GUARDIAN — IF EQUIPPED

Activation

Activate your account to enjoy advanced safety, security and convenience features.

1. Press the Apps icon on the bottom of your in-vehicle touchscreen.
2. Select the “Activate Services” icon from your list of apps.
3. Select “Customer Care” to speak with a SiriusXM Guardian Customer Care agent who will activate services in your vehicle, or select “Enter Email” to activate on the web.

Once you have activated your services, you're only a few steps away from using remote services.



Mobile App

Download the Uconnect mobile app:

- Once downloaded, use your Owner Account login and password to access the app.
- A PIN is required to execute remote services.
- Tap the “Location” button on the bottom menu bar of the app to locate your vehicle or send a destination to your Uconnect Navigation (if equipped).

- Tap the “Settings” side menu in the upper left corner of the app to bring up app settings and access the Assist Call Centers.

For further information:

- U.S. residents visit: siriusxm.com/guardian
- Canadian residents visit: siriusxm.ca/guardian/

Features

In-Vehicle

SiriusXM Guardian enhances your ownership and driving experience by connecting your vehicle to an operable network. When connected to an operable network, you have access to:

- SOS Call: Connect to a live agent who will contacts emergency services and stay on the line with you until help arrives.
- Customer Care Assistance: Speak with a live agent by pressing the ASSIST button on your rearview mirror to get Roadside Assistance or support.

Remote Services

- Vehicle Finder helps you find where you parked your car.
- Send & Go allows you to send destinations to your navigation system for easy access on the go.
- Remote Door Lock/Unlock lets you unlock or lock your doors from any distance.
- Remote Horn & Lights allows you to sound your horn and flash your lights to easily find your car.
- Receive monthly Vehicle Health Reports, and Alerts whenever a problem is detected under the hood.

Security Services

- Receive text or email notifications if your vehicle's security alarm goes off.
- Receive stolen vehicle assistance, using GPS technology to help authorities locate your vehicle if it is stolen.

SiriusXM Guardian remote services can be used with the Uconnect app from virtually anywhere.

For further information on SiriusXM Guardian or the Uconnect mobile App, refer to your Uconnect Owner's Manual Supplement.

Vehicle Finder And Send & Go

Vehicle Finder

Vehicle Finder allows you to find the location of your vehicle. To find your vehicle:

1. Press the “Location” tab on the Uconnect mobile App bottom bar.
2. Select the “Vehicle” icon to determine the location of your vehicle.
3. Select the “Find Route” button that appears, once your vehicle is located.
4. Select your preferred Navigation app to route a path to your vehicle.

Send & Go

To send an address to your Uconnect Navigation using the Uconnect mobile app:

1. Press the “Location” tab on the bottom bar of the Uconnect mobile app.
2. Type in the destination you would like to navigate to, or search through one of the categories provided.

3. Select the destination you want to send from the list that appears.
4. Press the “Send To Vehicle” button, and then confirm the destination by pressing “Yes,” to send the destination to the Uconnect Navigation in your vehicle.
5. Finally, confirm the destination inside your vehicle by pressing the “Go Now” option on the pop-up that appears on the touchscreen when the vehicle is started.

AMAZON ALEXA — IF EQUIPPED

Amazon Alexa Integration

Alexa is Amazon’s cloud-based voice service and it lets you voice-command your Uconnect system from just about anywhere you Alexa.

To link your Uconnect system to Amazon Alexa:

1. Download the Amazon Alexa app on your iPhone or Android.
2. Launch the app, then tap MENU, and go to SKILLS.
3. Search for your vehicle. Then tap “ENABLE.”
4. Select LINK ACCOUNT.
5. Log in using your vehicle’s Owner Account ID and password.

Examples of commands:

- “Alexa, ask Dodge Durango how much gas is in my vehicle.”
- “Alexa, ask Jeep Grand Cherokee to send directions to Iron Mountain to my vehicle.”
- “Alexa, ask Chrysler 300 to start my vehicle.”

ANDROID AUTO AND APPLE CARPLAY — IF EQUIPPED

Android Auto Integration



Android Auto

With easy touchscreen navigation and voice recognition, Android Auto brings useful information and organizes it into simple cards that appear just when they are needed.

1. Download the Android Auto app from the Google Play store on your Android-powered smartphone.

2. Connect your Android powered smartphone to one of the media USB ports in your vehicle. If the Android Auto app was not downloaded, it will begin to download when you plug in your device.
3. Once the device is connected and recognized, the “Phone” icon on the personalized menu bar will automatically change to the Android Auto icon.

Apple CarPlay Integration

Apple CarPlay is the smarter, safer way to use your iPhone to get directions with Apple Maps, listen to Apple Music, make calls and send messages — all through the Uconnect touchscreen or with your voice through Siri.



Apple CarPlay

To use CarPlay, make sure you are using iPhone 5 or later, have Siri enabled in Settings, ensure your iPhone is unlocked for the very first connection only, and then follow these steps:

1. Connect your iPhone to one of the media USB ports in your vehicle.
2. Once the device is connected and recognized, the “Phone” icon on the personalized menu bar will automatically change to the CarPlay icon.

DRIVE DODGE MOBILE APP

NOTE:

Long Press: Press and hold the VR button to activate Siri or Google Assistant.

Short Press: Briefly tap the VR button to activate the native Uconnect voice recognition system.

When using Android Auto or Apple CarPlay, be sure to use the factory-provided cable that came with your phone, as aftermarket cables may not work.

NOTE:

The Owner's Mobile App content is applicable to vehicles sold in the U.S. market and are not available from the Canadian App Store or Google Play Store.

Key Features

- Owner Information For Your Vehicle
- Accident Assistant
- Online Service Scheduling
- Roadside Assistance
- Maintenance History
- And More

To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword "Dodge".

The DRIVE DODGE Application is the essential app for owners of Dodge brand vehicles. The app puts driver and lifestyle information right in the palm of your hand, anywhere you go. Whether it's providing information about specific product features, taking a tour through your vehicle's equipment, staying up to date on your vehicle's health, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Dodge vehicle. Simply download the FREE app, select your make and model and enjoy the ride.

Features/Benefits

- Available for free on iOS and Android smartphones and tablets.
- Select Dodge brand vehicles from model year 2011 to current model year.
- You can also add other Chrysler, Jeep, Ram, FIAT or Alfa Romeo vehicles.*
- Easy access to vehicle information anywhere you go using categories, bookmarks, search and an A-Z index.
- Vehicle information such as operating instructions, maintenance, service history, vehicle controls and emergency procedures.
- Find a dealer or an FCA-certified repair facility.
- Easily document and email an accident report.
- A parking reminder that allows you to drop a pin on your location and navigate back to your vehicle.
- Contact customer care with one click.
- Access to vehicle heritage, parts, accessories, and social media networks.
- Schedule your next service appointment.
- Available in English and Spanish.

*App supports selected vehicles from model year 2011 to present.

To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword "Dodge".





Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident or scheduling your next appointment, we know you'll find the app an important extension of your Dodge brand vehicle. Simply download the app, select your make and model and enjoy the ride. To get this app, go directly to the App Store® or Google Play® Store and enter the search keyword "Dodge" (U.S. residents only).

www.dodge.com/en/owners (U.S.) provides special offers tailored to your needs, customized vehicle galleries, personalized service records and more. To get this information, just create an account and check back often.

Get warranty and other information online – you can review and print or download a copy of the Owner's Manual, Navigation/Uconnect manuals and the limited warranties provided by FCA US LLC for your vehicle by visiting www.dodge.com/en/owners (U.S.) or www.owners.mopar.ca (Canada). Click on the applicable link in the "Popular Topics" area of the www.dodge.com/en/owners (U.S.) or www.owners.mopar.ca (Canada) homepage and follow the instructions to select the applicable year, make and model of your vehicle.

DODGE

DOWNLOAD A FREE ELECTRONIC COPY
OF THE MOST UP-TO-DATE
OWNER'S MANUAL, MEDIA AND
WARRANTY BOOKLET BY VISITING:

WWW.MOPAR.COM/EN-US/CARE/OWNERS-MANUAL.HTML
(U.S. RESIDENTS)

WWW.OWNERS.MOPAR.CA (CANADIAN RESIDENTS)

DODGE.COM (U.S.)

DODGE.CA (CANADA)

©2018 FCA US LLC. ALL RIGHTS RESERVED.
DODGE IS A REGISTERED TRADEMARK OF FCA US LLC.
APP STORE IS A REGISTERED TRADEMARK OF APPLE INC.
GOOGLE PLAY STORE IS A REGISTERED TRADEMARK OF GOOGLE.



19LD-ORG-AA
SECOND EDITION